



THIS ALSO PROTRUDES,
INTERFERING WITH THE QTR
RND

The image shows a close-up of a door frame corner. A white quarter round molding is being installed. A wooden trim piece is visible on the left, and a wooden floor is at the bottom. Red arrows point from the text boxes to specific areas of the door frame and molding.

IM THINKING I NEED TO
NOTCH THE QTR RND AT
THIS BUMP OUT IN THE
DOOR FRAME SO THE END
CAN BUTT AGAINST THE
DOOR FRAME.

FRAME PROTRUDES FROM
WALL AND BOTTOM LIP.
SHOULD I UNDER CUT OR
NOTCH THE FLOORING?